

MICROFIBER CLOTH FROM PFENNIG Washing and care instructions



Thank you for choosing our professional microfiber cloth. To ensure that the microfiber cloth can be used as long and trouble-free as possible and to prevent premature wear, we would like to give you some recommendations for treatment and care.



First use

The microfiber cloths must be prewashed, sorted by color, at a maximum of 95°C (see label) before first use.



Varietal purity

Wash sorted by cotton and microfiber textiles.



Shake out

Remove coarse dust and dirt before washing.



Washing temperature

60° C to max. 95° C (see information on the label)



Dosage

Adjust the detergent dosage according to the water hardness and the degree of soiling.



Ratio

Washing machines should be loaded in a ratio of 1:5 (1 kg of laundry to 5 litres of water)



Washing programme

- 1. Prewash: 2 rinse cycles without detergent, with intermediate spin cycle
- 2. Prewash: Without detergent
- 3. Main wash cycle: Follow all detergent manufacturer's instructions
- 4. Rinse: 1st and 2nd rinse cycle with intermediate spin and 3rd final spin



Drying

Iron-dry, 8 to 12 % residual fibre moisture, max. blow-in temperature at max. 80° C

READY FOR USE!

Care instructions for qualified cleanroom microfibre cloths: The microfibre cloths must be specially prepared before use in the cleanroom, depending on the cleanroom class.



You can find more care instructions here!

pfennig-reinigungstechnik.com

Status: 01/2025

The Home of Clean